



APRILIA

RSV 1000 R/Factory	04 ~ 09				
	04 ~ 09				
	04 ~ 09				
RSV4 Factory	09 ~ 12				
	09 ~ 12				
	09 ~ 12				
RSV4 Factory/R ABS	13				
	13				
	13				
RSV4 Factory/R APR	11 ~ 12				
	11 ~ 12				
	11 ~ 12				
RSV4 R	09 ~ 12				
	09 ~ 12				
	09 ~ 12				
SRV 850	12 ~ 13				*1
Tuono	06 ~ 09				
	06 ~ 09				
	06 ~ 09				
Tuono V4R/APRC	11 ~ 13				
	11 ~ 13				
	11 ~ 13				

*1 1000rpm UP

